
DIGITAL KEYBOARD
CLAVIER NUMÉRIQUE
TECLADO DIGITAL


Drum Kit List

Liste des kits de batterie

Lista de juegos de batería

Liste der Drum Kits

EZ-300



EN

FR

ES

DE

Drum Kit List / Liste des kits de batterie / Lista de juegos de batería / Liste der Drum Kits

- Each percussion voice uses one-note polyphony.
- The MIDI Note # and Note are actually one octave lower than keyboard Note # and Note. For example, in "Standard Kit 1," the "Seq Click H" (Note #36/Note C1) corresponds to MIDI (Note #24/Note C0).
- Same as "Standard Kit 1"
- No Sound
- Chaque voix de percussion utilise une polyphonie s'appuyant sur une seule note.
- Les valeurs des paramètres MIDI Note # (Numéro de note MIDI) et Note sont en fait placées à une octave en deçà de l'octave du numéro de note et de la note de clavier. Par exemple, dans « Standard Kit 1 », « Seq Click H » (Numéro de note 36/Note C1) correspond à (Numéro de note 24/Note C0).
- Comme pour « Standard Kit 1 »
- Absence de son

Voice No.		242		243		244		245		246		247		248	
MSB (0-127) / LSB (0-127) / PC (1-128)		127/000/088		127/000/001		127/000/002		127/000/009		127/000/017		127/000/025		127/000/026	
Keyboard		MIDI		Power Kit		Standard Kit 1		Standard Kit 2		Room Kit		Rock Kit		Electronic Kit	
Note #	Note	Note #	Note	Note #	Note	Note #	Note	Note #	Note	Note #	Note	Note #	Note	Note #	Note
	25	C# 0	13	C# -1											
	26	D 0	14	D -1											
	27	D# 0	15	D# -1											
	28	E 0	16	E -1											
	29	F 0	17	F -1											
	30	F# 0	18	F# -1											
	31	G 0	19	G -1											
	32	G# 0	20	G# -1											
	33	A 0	21	A -1											
	34	A# 0	22	A# -1											
	35	B 0	23	B -1											
	36	C 1	24	C 0											
C1	C#1	37	C# 1	25	C# 0										
D1	D#1	38	D 1	26	D 0										
E1		39	D# 1	27	D# 0										
F1	F#1	40	E 1	28	E 0										
G1	G#1	41	F 1	29	F 0										
A1	A#1	42	F# 1	30	F# 0										
B1		43	G 1	31	G 0	Snare Soft Power	Snare Soft	Snare Soft 2		Snare Noisy	Snare Snappy Electronic	Snare Noisy 4			
C2	C#2	44	G# 1	32	G# 0		Sticks								
D2	D#2	45	A 1	33	A 0	Kick Amb+	Bass Drum Soft					Bass Drum H	Bass Drum H		
E2		46	A# 1	34	A# 0	Open Rim Power	Open Rim Shot	Open Rim Shot 2							
F2	F#2	47	B 1	35	B 0	Kick Power Open	Bass Drum Hard			Bass Drum H	Bass Drum Rock	Bass Drum Analog L			
G2	G#2	48	C 2	36	C 1	Kick Power Closed	Bass Drum	Bass Drum 2		Bass Drum Rock	Bass Drum Gate	Bass Drum Analog H			
A2	A#2	49	C# 2	37	C# 1	Side Stick Power	Side Stick					Side Stick Analog			
B2		50	D 2	38	D 1	Snare Power	Snare	Snare 2	Snare Room L	Snare Rock	Snare Noisy 2	Snare Analog 1			
C3	C#3	51	D# 2	39	D# 1	Hand Clap Power	Hand Clap								
D3	D#3	52	E 2	40	E 1	Snare Rough	Snare Tight	Snare Tight 2	Snare Room H	Snare Rock Rim	Snare Noisy 3	Snare Analog 2			
E3	F#3	53	F 2	41	F 1	Tom Power 1	Floor Tom L		Tom Room 1	Tom Rock 1	Tom Electronic 1	Tom Analog 1			
F3	G#3	54	F# 2	42	F# 1	Hi-Hat Closed Power	Hi-Hat Closed					Hi-Hat Closed Analog 1			
G3	A#3	55	G 2	43	G 1	Tom Power 2	Floor Tom H		Tom Room 2	Tom Rock 2	Tom Electronic 2	Tom Analog 2			
A3		56	G# 2	44	G# 1	Hi-Hat Pedal Power	Hi-Hat Pedal					Hi-Hat Closed Analog 2			
B3		57	A 2	45	A 1	Tom Power 3	Low Tom		Tom Room 3	Tom Rock 3	Tom Electronic 3	Tom Analog 3			
C4	C#4	58	A# 2	46	A# 1	Hi-Hat Open Power	Hi-Hat Open					Hi-Hat Open Analog			
D4	D#4	59	B 2	47	B 1	Tom Power 4	Mid Tom L		Tom Room 4	Tom Rock 4	Tom Electronic 4	Tom Analog 4			
E4	F#4	60	C 3	48	C 2	Tom Power 5	Mid Tom H		Tom Room 5	Tom Rock 5	Tom Electronic 5	Tom Analog 5			
F4	G#4	61	C# 3	49	C# 2	Crash Cymbal Acoustic 1	Crash Cymbal 1					Crash Analog			
G4	A#4	62	D 3	50	D 2	Tom Power 6	High Tom		Tom Room 6	Tom Rock 6	Tom Electronic 6	Tom Analog 6			
A4		63	D# 3	51	D# 2	Ride Cymbal Acoustic 1	Ride Cymbal 1								
B4		64	E 3	52	E 2	Chinese Cymbal Acoustic	Chinese Cymbal								
C5	C#5	65	F 3	53	F 2	Ride Cymbal Cup Acoustic	Ride Cymbal Cup								
D5	D#5	66	F# 3	54	F# 2		Tambourine								
E5	F#5	67	G 3	55	G 2	Splash Cymbal Acoustic	Splash Cymbal								
F5	G#5	68	G# 3	56	G# 2		Cowbell								
G5	A#5	69	A 3	57	A 2	Crash Cymbal Acoustic 2	Crash Cymbal 2								
A5		70	A# 3	58	A# 2		Vibraslap								
B5		71	B 3	59	B 2	Ride Cymbal Acoustic 2	Ride Cymbal 2								
C6		72	C 4	60	C 3		Bongo H								
		73	C# 4	61	C# 3		Bongo L								
		74	D 4	62	D 3		Conga H Mute						Conga Analog H		
		75	D# 4	63	D# 3		Conga H Open						Conga Analog M		
		76	E 4	64	E 3		Conga L						Conga Analog L		
		77	F 4	65	F 3		Timbale H								
		78	F# 4	66	F# 3		Timbale L								
		79	G 4	67	G 3		Agogo H								
		80	G# 4	68	G# 3		Agogo L								
		81	A 4	69	A 3		Cabasa								
		82	A# 4	70	A# 3		Maracas						Maracas 2		
		83	B 4	71	B 3		Samba Whistle H								
		84	C 5	72	C 4		Samba Whistle L								
		85	C# 5	73	C# 4		Guiro Short								
		86	D 5	74	D 4		Guiro Long								
		87	D# 5	75	D# 4		Claves						Claves 2		
		88	E 5	76	E 4		Wood Block H								
		89	F 5	77	F 4		Wood Block L								
		90	F# 5	78	F# 4		Cuica Mute						Scratch H	Scratch H	
		91	G 5	79	G 4		Cuica Open						Scratch L	Scratch L	
		92	G# 5	80	G# 4		Triangle Mute								
		93	A 5	81	A 4		Triangle Open								
		94	A# 5	82	A# 4		Shaker								
		95	B 5	83	B 4		Jingle Bells								
		96	C 6	84	C 5	Wind Chime	Bell Tree								
		97	C# 6	85	C# 5										
		98	D 6	86	D 5										
		99	D# 6	87	D# 5										
		100	E 6	88	E 5										
		101	F 6	89	F 5										
		102	F# 6	90	F# 5										
		103	G 6	91	G 5										

Drum Kit List / Liste des kits de batterie / Lista de juegos de batería / Liste der Drum Kits

- Cada voz de percusión utiliza una polifonía de una nota.
- El número de nota y la nota MIDI son en realidad una octava menos que el número de nota y la nota en el teclado. Por ejemplo, en el juego "Standard Kit 1", la nota "Seq Click H", que tiene el número de nota 36 y el nombre de nota C1 (do1) en el teclado, corresponden, en MIDI, al número de nota 24 y a la nota C0 (do0).
- Igual que el "Standard Kit 1"
- Sin sonido

- Jedes Schlaginstrument verwendet eine Ein-Noten-Polyphonie.
- MIDI-Note # und MIDI Note sind in Wirklichkeit eine Oktave tiefer als hier aufgeführt. Im „Standard Kit 1“ beispielsweise entspricht „Seq Click H“ (Note # 36/Note C1) den MIDI-Werten (Note # 24/Note C0).
- Entspricht „Standard Kit 1“
- Kein Ton

Voice No.		243		249		250		251		252		253		254	
MSB (0-127) / LSB (0-127) / PC (1-128)		127/000/001		127/000/113		127/000/033		127/000/041		127/000/049		126/000/128		126/000/040	
Keyboard		MIDI		Standard Kit 1		Dance Kit		Jazz Kit		Brush Kit		Symphony Kit		StdKit 1 + Chinese Perc.	
Note #	Note	Note #	Note	Note #	Note	Note #	Note	Note #	Note	Note #	Note	Note #	Note	Note #	Note
	25	C# 0	13	C# -1	Surdo Mute										
	26	D 0	14	D -1	Surdo Open										
	27	D# 0	15	D# -1	Hi Q										
	28	E 0	16	E -1	Whip Slap										
	29	F 0	17	F -1	Scratch H										
	30	F# 0	18	F# -1	Scratch L										
	31	G 0	19	G -1	Finger Snap										
	32	G# 0	20	G# -1	Click Noise										
	33	A 0	21	A -1	Metronome Click										
	34	A# 0	22	A# -1	Metronome Bell										
	35	B 0	23	B -1	Seq Click L										
	36	C 1	24	C 0	Seq Click H										
C1	C#1	37	C# 1	25	C# 0	Brush Tap									
D1	D#1	38	D 1	26	D 0	Brush Swirl									
E1		39	D# 1	27	D# 0	Brush Slap									
F1	F#1	40	E 1	28	E 0	Brush Tap Swirl	Reverse Cymbal								
G1	G#1	41	F 1	29	F 0	Snare Roll									
A1	A#1	42	F# 1	30	F# 0	Castanet	Hi Q 2								
B1		43	G 1	31	G 0	Snare Soft	Snare Techno		Brush Slap 2						
C2	C#2	44	G# 1	32	G# 0	Sticks									
D2	D#2	45	A 1	33	A 0	Bass Drum Soft	Kick Techno Q			Bass Drum Soft L					
E2		46	A# 1	34	A# 0	Open Rim Shot	Rim Gate								
F2	F#2	47	B 1	35	B 0	Bass Drum Hard	Kick Techno L				Gran Cassa				
G2	G#2	48	C 2	36	C 1	Bass Drum	Kick Techno	Bass Drum Jazz	Bass Drum Jazz	Gran Cassa Mute					
A2	A#2	49	C# 2	37	C# 1	Side Stick	Side Stick Analog								
B2		50	D 2	38	D 1	Snare	Snare Clap	Snare Jazz L	Brush Slap 3	Band Snare 1					
C3	C#3	51	D# 2	39	D# 1	Hand Clap									
D3	D#3	52	E 2	40	E 1	Snare Tight	Snare Dry	Snare Jazz M	Brush Tap	Band Snare 2					
E3		53	F 2	41	F 1	Floor Tom L	Tom Analog 1	Tom Jazz 1	Tom Brush 1	Tom Jazz 1					
F3	F#3	54	F# 2	42	F# 1	Hi-Hat Closed	Hi-Hat Closed Analog 3								
G3	G#3	55	G 2	43	G 1	Floor Tom H	Tom Analog 2	Tom Jazz 2	Tom Brush 2	Tom Jazz 2					
A3	A#3	56	G# 2	44	G# 1	Hi-Hat Pedal	Hi-Hat Closed Analog 4								
B3		57	A 2	45	A 1	Low Tom	Tom Analog 3	Tom Jazz 3	Tom Brush 3	Tom Jazz 3					
C4	C#4	58	A# 2	46	A# 1	Hi-Hat Open	Hi-Hat Open Analog 2								
D4	D#4	59	B 2	47	B 1	Mid Tom L	Tom Analog 4	Tom Jazz 4	Tom Brush 4	Tom Jazz 4					
E4		60	C 3	48	C 2	Mid Tom H	Tom Analog 5	Tom Jazz 5	Tom Brush 5	Tom Jazz 5					
F4	F#4	61	C# 3	49	C# 2	Crash Cymbal 1	Crash Analog			Hand Cymbal 1					
G4	G#4	62	D 3	50	D 2	High Tom	Tom Analog 6	Tom Jazz 6	Tom Brush 6	Tom Jazz 6					
A4	A#4	63	D# 3	51	D# 2	Ride Cymbal 1				Hand Cymbal 1 Short					
B4		64	E 3	52	E 2	Chinese Cymbal									
C5	C#5	65	F 3	53	F 2	Ride Cymbal Cup									
D5	D#5	66	F# 3	54	F# 2	Tambourine									
E5		67	G 3	55	G 2	Splash Cymbal									
F5	F#5	68	G# 3	56	G# 2	Cowbell	Cowbell Analog								
G5	G#5	69	A 3	57	A 2	Crash Cymbal 2				Hand Cymbal 2					
A5	A#5	70	A# 3	58	A# 2	Vibraslap									
B5		71	B 3	59	B 2	Ride Cymbal 2				Hand Cymbal 2 Short					
C6	C#6	72	C 4	60	C 3	Bongo H									
D6	D#6	73	C# 4	61	C# 3	Bongo L									
E6		74	D 4	62	D 3	Conga H Mute	Conga Analog H								
F6	F#6	75	D# 4	63	D# 3	Conga H Open	Conga Analog M								
G6	G#6	76	E 4	64	E 3	Conga L	Conga Analog L								
A6	A#6	77	F 4	65	F 3	Timbale H									
B6		78	F# 4	66	F# 3	Timbale L									
C7	C#7	79	G 4	67	G 3	Agogo H									
D7	D#7	80	G# 4	68	G# 3	Agogo L									
E7		81	A 4	69	A 3	Cabasa									
F7	F#7	82	A# 4	70	A# 3	Maracas	Maracas 2								
G7	G#7	83	B 4	71	B 3	Samba Whistle H									
A7	A#7	84	C 5	72	C 4	Samba Whistle L									
B7		85	C# 5	73	C# 4	Guiro Short									
C8	C#8	86	D 5	74	D 4	Guiro Long									
D8	D#8	87	D# 5	75	D# 4	Claves	Claves 2								
E8		88	E 5	76	E 4	Wood Block H									
F8	F#8	89	F 5	77	F 4	Wood Block L									
G8	G#8	90	F# 5	78	F# 4	Cuica Mute	Scratch H								
A8	A#8	91	G 5	79	G 4	Cuica Open	Scratch L								
B8		92	G# 5	80	G# 4	Triangle Mute									
C9	C#9	93	A 5	81	A 4	Triangle Open									
D9	D#9	94	A# 5	82	A# 4	Shaker									
E9		95	B 5	83	B 4	Jingle Bells									
F9	F#9	96	C 6	84	C 5	Bell Tree									
G9	G#9	97	C# 6	85	C# 5										
A9	A#9	98	D 6	86	D 5										
B9		99	D# 6	87	D# 5										
C10	C#10	100	E 6	88	E 5										
D10	D#10	101	F 6	89	F 5										
E10		102	F# 6	90	F# 5										
F10	F#10	103	G 6	91	G 5										

Drum Kit List / Liste des kits de batterie / Lista de juegos de batería / Liste der Drum Kits

Voice No.		243		255		256		257		258		259	
MSB (0-127) / LSB (0-127) / PC (1-128)		127/000/001		126/000/115		126/000/055		126/000/056		126/000/057		126/000/037	
Keyboard		MIDI		Standard Kit 1		Indian Kit 2		StdKit 1 + Indonesian Perc. 1		StdKit 1 + Indonesian Perc. 2		StdKit 1 + Indonesian Perc. 3	
Note #	Note	Note #	Note									Arabic Kit	
25	C# 0	13	C# -1	Surdo Mute						Low Dut Slide 1		Zarb Back mf	
26	D 0	14	D -1	Surdo Open						Low Dut Slide 2		Zarb Tom f	
27	D# 0	15	D# -1	Hi Q		Indian Hand Clap				Low Dut Slide 3		Zarb Eshareh	
28	E 0	16	E -1	Whip Slap		Dafli Open				Plak 2 Ring Open		Zarb Whipping	
29	F 0	17	F -1	Scratch H		Dafli Slap				Plak 2 Ring Mute		Tombak Tom f	
30	F# 0	18	F# -1	Scratch L		Dafli Rim				Plak 2 Mute Center		Neghareh Tom f	
31	G 0	19	G -1	Finger Snap		Duff Open				Plak 2 Open		Tombak Back f	
32	G# 0	20	G# -1	Click Noise		Duff Slap						Neghareh Back f	
33	A 0	21	A -1	Metronome Click		Duff Rim						Tombak Snap f	
34	A# 0	22	A# -1	Metronome Bell		Hatheli Long						Neghareh Pelang f	
35	B 0	23	B -1	Seq Click L		Hatheli Short						Tombak Trill	
36	C 1	24	C 0	Seq Click H		Baya ge						Khaligi Clap 1	
37	C# 1	25	C# 0	Brush Tap		Baya ke						Arabic Zalgouta Open	
38	D 1	26	D 0	Brush Swirl		Baya ghe						Khaligi Clap 2	
39	D# 1	27	D# 0	Brush Slap		Baya ka						Arabic Zalgouta Close	
40	E 1	28	E 0	Brush Tap Swirl		Tabla na						Arabic Hand Clap	
41	F 1	29	F 0	Snare Roll		Tabla tin						Tabel Tak 1	
42	F# 1	30	F# 0	Castanet		Tablabaya dha						Sagat 1	
43	G 1	31	G 0	Snare Soft		Dhol 1 Open						Tabel Dom	
44	G# 1	32	G# 0	Sticks		Dhol 1 Slap						Sagat 2	
45	A 1	33	A 0	Bass Drum Soft		Dhol 1 Mute						Tabel Tak 2	
46	A# 1	34	A# 0	Open Rim Shot		Dhol 1 Open Slap						Sagat 3	
47	B 1	35	B 0	Bass Drum Hard		Dhol 1 Roll						Riq Tik 3	
48	C 2	36	C 1	Bass Drum		Dandia Short						Riq Tik 2	
49	C# 2	37	C# 1	Side Stick		Dandia Long						Riq Tik Hard 1	
50	D 2	38	D 1	Snare		Chutki						Riq Tik 1	
51	D# 2	39	D# 1	Hand Clap		Chipri						Riq Tik Hard 2	
52	E 2	40	E 1	Snare Tight		Khanjira Open						Riq Tik Hard 3	
53	F 2	41	F 1	Floor Tom L		Khanjira Slap						Riq Tish	
54	F# 2	42	F# 1	Hi-Hat Closed		Khanjira Mute						Riq Snouj 2	
55	G 2	43	G 1	Floor Tom H		Khanjira Bendup						Riq Roll	
56	G# 2	44	G# 1	Hi-Hat Pedal		Khanjira Benddown						Riq Snouj 1	
57	A 2	45	A 1	Low Tom		Dholak 1 Open						Riq Sak	
58	A# 2	46	A# 1	Hi-Hat Open		Dholak 1 Mute						Riq Snouj 3	
59	B 2	47	B 1	Mid Tom L		Dholak 1 Slap						Riq Snouj 4	
60	C 3	48	C 2	Mid Tom H		Dhol 2 Open						Riq Tak 1	
61	C# 3	49	C# 2	Crash Cymbal 1		Dhol 2 Slap						Riq Brass 1	
62	D 3	50	D 2	High Tom		Dhol 2 Rim						Riq Tak 2	
63	D# 3	51	D# 2	Ride Cymbal 1		Mridangam na						Riq Brass 2	
64	E 3	52	E 2	Chinese Cymbal		Mridangam din						Riq Dom	
65	F 3	53	F 2	Ride Cymbal Cup		Mridangam ki						Katem Tak Doff	
66	F# 3	54	F# 2	Tambourine		Mridangam ta						Katem Dom	
67	G 3	55	G 2	Splash Cymbal		Mridangam Chapu						Katem Sak 1	
68	G# 3	56	G# 2	Cowbell		Mridangam Lo Closed						Katem Tak 1	
69	A 3	57	A 2	Crash Cymbal 2		Mridangam Lo Open						Katem Sak 2	
70	A# 3	58	A# 2	Vibraslap		Chimta Normal						Katem Tak 2	
71	B 3	59	B 2	Ride Cymbal 2		Chimta Ring						Daholla Sak 2	
72	C 4	60	C 3	Bongo H		Dholki Hi Open		Kendang Ageng Dah		Tamborine Hit		Tamborine Hit	
73	C# 4	61	C# 3	Bongo L		Dholki Hi Mute		Kendang Tipung Thung 1		Tamborine Hit Mute		Tamborine Hit Mute	
74	D 4	62	D 3	Conga H Mute		Dholki Lo Open		Kendang Ciblon Dhen		Duf Open		Dut Open	
75	D# 4	63	D# 3	Conga H Open		Dholki Hi Slap		Kendang Ciblon Det		Duf Slide		Dut Slide	
76	E 4	64	E 3	Conga L		Dholki Lo Slide		Kendang Ciblon Thung		Duf Center Mute		Dut Slide Long	
77	F 4	65	F 3	Timbale H		Khol Open		Kendang Ciblon Lung 1		Duf Slap Mute		Dut Slide Short	
78	F# 4	66	F# 3	Timbale L		Khol Slide		Kendang Ciblon Thak 1		Duf Ring Mute		Dut Palm Half Mute	
79	G 4	67	G 3	Agogo H		Khol Mute		Kendang Ciblon Thak 2		Bayan Duf Open		Dut Palm Slide 1	
80	G# 4	68	G# 3	Agogo L		Manjira Open		Kendang Tipung Thung 2		Bayan Duf Slap Mute		Dut Palm Slide 2	
81	A 4	69	A 3	Cabasa		Manjira Close		Kendang Tipung Ket		Bayan Duf Slide		Dut Mute	
82	A# 4	70	A# 3	Maracas		Jhanji Open		Kendang Ciblon Lung 2		Bayan Duf Ring Mute		Tung Open 3	
83	B 4	71	B 3	Samba Whistle H		Jhanji Close		Kendang Ciblon Tong		Dayan Finger Tips 4		Tung Side	
84	C 5	72	C 4	Samba Whistle L		Mondira Open		Plak 1 Ring Mute		Tung Finger Tips 1		Keplak Open	
85	C# 5	73	C# 4	Guiro Short		Mondira Close		Plak 1 Mute Center		Tung Finger Tips 2		Keplak Mute	
86	D 5	74	D 4	Guiro Long		Indian Bhangra Scat 1		Tung Open 1		Dayan Finger Tips 1		Keplak Finger Tips 1	
87	D# 5	75	D# 4	Claves		Indian Bhangra Scat 2		Low Dut Open		Dayan Ring Mute		Keplak Finger Tips 2	
88	E 5	76	E 4	Wood Block H		Indian Bhangra Scat 3		Low Dut Mute 1		Dayan Finger Tips 3		Tak Open Center	
89	F 5	77	F 4	Wood Block L		Indian Bhangra Scat 4		Low Dut Mute 2		Dayan Ring Open		Tak Open Rim 1	
90	F# 5	78	F# 4	Cuica Mute		Khomokh Normal		Low Dut Mute 3		Dayan Finger Tips 2		Tak Open Rim 2	
91	G 5	79	G 4	Cuica Open		Khomokh Mute		Low Dut Mute 4		Dayan Open		Tak Center Mute	
92	G# 5	80	G# 4	Triangle Mute		Khomokh Miltak		Low Dut Slide 1		Dayan Center Mute		Tak Ring Mute	
93	A 5	81	A 4	Triangle Open		Thavil Open		Low Dut Slide 2		Tung Open 2		Prang Slap Mute	
94	A# 5	82	A# 4	Shaker		Thavil Slap		Low Dut Slide 3		Plak 1 Mute Center		Prang Finger Tips Flam	
95	B 5	83	B 4	Jingle Bells		Thavil Mute		Plak 2 Ring Open		Low Dut Mute 1		Plak 1 Ring Mute	
96	C 6	84	C 5	Bell Tree		Khartaal				Low Dut Mute 3		Plak 1 Mute Center	
97	C# 6	85	C# 5			Dholak 2 Open				Low Dut Slide 3		Tung Open 1	
98	D 6	86	D 5			Dholak 2 Slide				Plak 2 Mute Center		Low Dut Open	
99	D# 6	87	D# 5			Dholak 2 Rim 1				Plak 2 Open		Low Dut Mute 1	
100	E 6	88	E 5			Dholak 2 Rim 2						Low Dut Mute 2	
101	F 6	89	F 5			Dholak 2 Ring						Low Dut Mute 3	
102	F# 6	90	F# 5			Dholak 2 Slap						Low Dut Mute 4	
103	G 6	91	G 5										

Drum Kit List / Liste des kits de batterie / Lista de juegos de batería / Liste der Drum Kits

* Actual keyboard notes of the SFX Kit 1 and 2 are one octave lower than the ones described in the list.

* Las notas reales del teclado del SFX Kit 1 y 2 son una octava más bajas que las que se describen en la lista.

* Les notes des kits SFX 1 et 2 qui retentissent réellement au clavier sont à une octave inférieure à celles qui sont décrites dans la liste.

* Die tatsächlichen Tastaturnoten des SFX Kit 1 und 2 sind eine Oktave tiefer als die in der Liste beschrieben.

		Voice No.		243	260	261	262	263
		MSB (0-127) / LSB (0-127) / PC (1-128)		127/000/001	126/000/041	126/000/001	126/000/002	126/000/113
		Keyboard		Standard Kit 1	Cuban Kit	SFX Kit 1 *	SFX Kit 2 *	Sound Effect Kit
		Note #	Note	Note #	Note	Note #	Note	Note #
		25	C# 0	13	C# -1			
		26	D 0	14	D -1			
		27	D# 0	15	D# -1			
		28	E 0	16	E -1			
		29	F 0	17	F -1			
		30	F# 0	18	F# -1			
		31	G 0	19	G -1			
		32	G# 0	20	G# -1			
		33	A 0	21	A -1			
		34	A# 0	22	A# -1			
		35	B 0	23	B -1			
		36	C 1	24	C 0			
C1	C#1	37	C# 1	25	C# 0			
D1	D#1	38	D 1	26	D 0			
E1		39	D# 1	27	D# 0			
F1	F#1	40	E 1	28	E 0			
G1	G#1	41	F 1	29	F 0			
A1	A#1	42	F# 1	30	F# 0			
B1		43	G 1	31	G 0			
C2	C#2	44	G# 1	32	G# 0			
D2	D#2	45	A 1	33	A 0			
E2		46	A# 1	34	A# 0			
F2	F#2	47	B 1	35	B 0			
G2	G#2	48	C 2	36	C 1			
A2	A#2	49	C# 2	37	C# 1			
B2		50	D 2	38	D 1			
C3	C#3	51	D# 2	39	D# 1			
D3	D#3	52	E 2	40	E 1			
E3		53	F 2	41	F 1			
F3	F#3	54	F# 2	42	F# 1			
G3	G#3	55	G 2	43	G 1			
A3	A#3	56	G# 2	44	G# 1			
B3		57	A 2	45	A 1			
C4	C#4	58	A# 2	46	A# 1			
D4	D#4	59	B 2	47	B 1			
E4		60	C 3	48	C 2			
F4	F#4	61	C# 3	49	C# 2			
G4	G#4	62	D 3	50	D 2			
A4	A#4	63	D# 3	51	D# 2			
B4		64	E 3	52	E 2			
C5	C#5	65	F 3	53	F 2			
D5	D#5	66	F# 3	54	F# 2			
E5		67	G 3	55	G 2			
F5	F#5	68	G# 3	56	G# 2			
G5	G#5	69	A 3	57	A 2			
A5	A#5	70	A# 3	58	A# 2			
B5		71	B 3	59	B 2			
C6		72	C 4	60	C 3			
		73	C# 4	61	C# 3			
		74	D 4	62	D 3			
		75	D# 4	63	D# 3			
		76	E 4	64	E 3			
		77	F 4	65	F 3			
		78	F# 4	66	F# 3			
		79	G 4	67	G 3			
		80	G# 4	68	G# 3			
		81	A 4	69	A 3			
		82	A# 4	70	A# 3			
		83	B 4	71	B 3			
		84	C 5	72	C 4			
		85	C# 5	73	C# 4			
		86	D 5	74	D 4			
		87	D# 5	75	D# 4			
		88	E 5	76	E 4			
		89	F 5	77	F 4			
		90	F# 5	78	F# 4			
		91	G 5	79	G 4			
		92	G# 5	80	G# 4			
		93	A 5	81	A 4			
		94	A# 5	82	A# 4			
		95	B 5	83	B 4			
		96	C 6	84	C 5			
		97	C# 6	85	C# 5			
		98	D 6	86	D 5			
		99	D# 6	87	D# 5			
		100	E 6	88	E 5			
		101	F 6	89	F 5			
		102	F# 6	90	F# 5			
		103	G 6	91	G 5			