

Previous TF Editor version Information

V4.02

Fixed Bugs (V4.02)

- Solved the problem in which the recall safe status would not be updated when loading a settings file (.TFF file) to version 4.00/4.01 of the TF5/F3/TF1/TF-RACK or version 4.00 of the TF Editor.

Additional Functions (V4.00)

- The Selected Channel section has been added to the OVERVIEW screen, allowing you to edit sounds for each channel in a single screen. To display the Selected Channel section, set the "CH Strip & Selected Channel" of the Home Button Function in the Setup menu to ON.
- Added the FADE TIME function for Scene. Only the FADE TIME setting is available in the TF Editor.
- Added MUTE GROUP 3 to MUTE GROUP 6 to which channels are freely assignable. To assign channels, use the MUTE GROUP ASSIGN screen of the SETUP screen, or the ASSIGN screen of each channel.
- The "ON" and "Fader" parameters for the recall safe function can now be set individually.
- Added Copy/Paste to the menu of the SEND FROM screen, to copy/paste the SEND level for the AUX/MATRIX/SUB channels.
- Added CH Copy with Sends/CH Paste with Sends to the menu of the AUX/MATRIX/SUB channels.
- Added the Group Bypass function to the AUTOMIXER screen.
- Added assignable functions to the USER DEFINED KEYS and the FOOT SWITCH.
 - Group Bypass and Channel ON/OFF for the Automixer
 - MUTE GROUP 3 to MUTE GROUOP 6 for the Mute Master
- Added the Channel Delay function to the ST IN 1/2 channels.
- Added new Presets to the Channel Library. Also, some previous Presets have been modified.

Specification Changes (V4.00)

- Changed the CH STRIP area's ON button operation when the Mute Group Master is ON.

V3.60

New feature (V3.60)

- The "RTA Offset" function has been added and can be assigned to the [USER DEFINED KNOBS] on the USER DEFINED CONTROLS screen.

V3.51

New features (V3.51)

- Now supports macOS 10.14.

Fixed bug (V3.51)

- Solved a problem in which, when using the TF Editor V3.50 in TF5 or TF3 mode, operating the Stereo Link function in the Input List screen might force the application to close.

New features (V3.50)

- Channels 1 – 8 can be used with the Dugan Automixer.
Scenes saved via the TF series V3.11 or earlier do not include the Automixer parameters. This means that Automixer parameters will not change even such Scenes are recalled.
- Added AUX Send point selection, Pre EQ or Pre Fader, for a channel to which AUX Send is set to Pre.
- Added the "frame" unit for the Delay Time parameter setting in the Monitor Delay effect of OUTPUT channels and the OUTPUT DELAY effect.
- Added the PFL Trim setting in the MONITOR CUE screen.
- Added the stereo pair setting for the MATRIX1/2 bus and MATRIX 3/4 bus.
- Added "MONITOR" in the OUTPUT tab on the INPUT LIST screen. Only patching to the OMNI OUT is available.

Specification changes (V3.50)

- Changed the “Last CUE” mode to the CUE stack* operation, same as with the “MIX CUE” mode.

*CUE stack: turning off the CUE for a low priority channel enables the CUE for a high priority channel to be turned on again.

- Changed the [ON] button function of the CH STRIP area when the [INPUT] button or the [FX] button of the MUTE area is turned on.

V3.11 or earlier: Pressing an [ON] button turns the temporary cancelation for mute function on/off

V3.50 or later: Pressing an [ON] button temporary removes the channel from the mute group

V3.10

New features

- Added the “Input List” screen to view and edit channel names, channel colors, channel icons, etc. for each channel of the TF series in a list form.

V3.01 (Win)

Additional Function

- Now supports the TF-RACK.
- Ensured that the STEREO/SUB Level Link function maintains offsets.

[NOTICE]

Offset values will also be saved in a Scene. However, Scenes saved via the TF series V2.50 or earlier do not include Offset values. This means that Offset values will not change even if such Scenes are recalled.

- Added bus sends from the AUX9/10 – AUX19/20 busses to the SUB bus.
- Added a SEND FROM screen to the FX1/FX2 channels.
- Added the Matrix1-4 meters in the TOOLBAR.
- New Presets have been added to the default Presets of the Channel Library. To add them to the Library list, execute “Initialize All Memory” after updating to V3.0.

Specification changes(V3.00)

- Added the threshold link function of the “Multi Band Comp” effect to keep offsets between the Low, Mid, and High parameters. In addition, the Make Up parameter has been removed to avoid a sudden change of volume.
- Changed the Input Gain offset link action between stereo link channels to keep the offset value even if the Input Gain is set to maximum or minimum.
- The SYSTEM SETUP screen and the USER SETUP screen have been consolidated to the SETUP screen.
- Connection to a TF series unit now requires the Administrator password.
- Changed the specification to not load the settings of channel selection, fader bank selection, and SENDS ON FADER in the TF setting file (.TFF).
- The available file type in the browser window displays when executing Load/Save/Save As menu has been unified to the .TFF file.

Specification changes(V3.01)

- (TF-RACK only) Changed OMNI OUT Patch settings of the Preset Scenes to “ST L=OMNI 7” and “ST R=OMNI 8,” which matches the rear panel printing.
This change will be reflected when executing the “Initialize All Memory” function after updating to V3.01.

Improvements

- The separator in the Manage Library/Scene screen allows you to change sizes of left and right panes. In addition, the layout has been changed.

Fixed bugs(V3.00)

- Solved a problem in which executing the “Initialize Memory” menu caused a forced termination of the TF Editor while the INPUT screen of the ST IN channel was displayed.
- Solved a problem in which operating a category of the MATRIX channel Library in the Manage Library/Scene screen caused a forced termination of the TF Editor.
- Solved a problem in which the Send Pan parameter set to center when executing the “All Nominal” context menu in the SEND FROM screen.
- Solved some minor bugs.

Fixed bugs(V3.01)

- Solved a problem in which, when operating the analog gain (A.Gain) of a channel not set to the Stereo Link function, and if Stereo Link has been set to the channel using the same INPUT jack (TF5:CH1-8 and CH33-40, TF3:CH1-16 and CH25-40, TF1:CH1-16 and CH17-32), the unlinked channel would also link to the corresponding next channel regardless of the input source selection.

Known issue

- When updating the TF Editor from V2.50 or earlier to V3.00, the network interface selection will be initialized. Select a network interface to connect the TF Editor and the TF series unit via “Setup” -> “Network Interface” menu as necessary.

V3.01 (Mac)

Additional Function

- Now supports the TF-RACK.
- Ensured that the STEREO/SUB Level Link function maintains offsets.

[NOTICE]

Offset values will also be saved in a Scene. However, Scenes saved via the TF series V2.50 or earlier do not include Offset values. This means that Offset values will not change even if such Scenes are recalled.

- Added bus sends from the AUX9/10 – AUX19/20 busses to the SUB bus.
- Added a SEND FROM screen to the FX1/FX2 channels.
- Added the Matrix1-4 meters in the TOOLBAR.
- New Presets have been added to the default Presets of the Channel Library. To add them to the Library list, execute “Initialize All Memory” after updating to V3.0.

Specification changes(V3.00)

- Added the threshold link function of the “Multi Band Comp” effect to keep offsets between the Low, Mid, and High parameters. In addition, the Make Up parameter has been removed to avoid a sudden change of volume.
- Changed the Input Gain offset link action between stereo link channels to keep the offset value even if the Input Gain is set to maximum or minimum.
- The SYSTEM SETUP screen and the USER SETUP screen have been consolidated to the SETUP screen.

- Connection to a TF series unit now requires the Administrator password.
- Changed the specification to not load the settings of channel selection, fader bank selection, and SENDS ON FADER in the TF setting file (.TFF).
- The available file type in the browser window displays when executing Load/Save/Save As menu has been unified to the .TFF file.

Specification changes(V3.01)

- (TF-RACK only) Changed OMNI OUT Patch settings of the Preset Scenes to “ST L=OMNI 7” and “ST R=OMNI 8,” which matches the rear panel printing.
This change will be reflected when executing the “Initialize All Memory” function after updating to V3.01.

Improvements

- The separator in the Manage Library/Scene screen allows you to change sizes of left and right panes. In addition, the layout has been changed.

Fixed bugs(V3.00)

- Solved a problem in which operating a category of the MATRIX channel Library in the Manage Library/Scene screen caused a forced termination of the TF Editor.
- Solved a problem in which the Send Pan parameter set to center when executing the “All Nominal” context menu in the SEND FROM screen.
- Solved some minor bugs.

Fixed bugs(V3.01)

- Solved a problem in which, when operating the analog gain (A.Gain) of a channel not set to the Stereo Link function, and if Stereo Link has been set to the channel using the same INPUT jack (TF5:CH1-8 and CH33-40, TF3:CH1-16 and CH25-40, TF1:CH1-16 and CH17-32), the unlinked channel would also link to the corresponding next channel regardless of the input source selection.

Known issue

- When updating the TF Editor from V2.50 or earlier to V3.00, the network interface selection will be initialized. Select a network interface to connect the TF Editor and the TF series unit via “Setup” -> “Network Interface” menu as necessary.

V2.00 (Win)

Additional Function

- Added “Ping Pong Delay” and “Dual Pitch” effect types.
- Added the “Manage Library/Scene” window to manage Libraries and Scenes.
- Added the menu to open the website for downloading Channel Libraries (QuickPro Presets).
- Added the “All Nominal” function to set the send level settings of all AUX busses or SUB bus to nominal (0 dB) in the menu of each SEND FROM screen.
- Added the “Dup. STEREO” function to set the send level settings of AUX busses or SUB bus to the same settings of the channel faders in the menu of each SEND FROM screen.
- Added the function to send to the SUB bus from ST IN1/2 or FX RTN 1/2.

NOTE

When recalling a Scene, or a Channel Library stored via the V1.xx version, these send parameters are not changed.

- Added some default Presets in the Channel Library. Some Preset data have been modified. This change will be reflected when executing the “Initialize All Memory” function after updating to V2.00.

Specification Changes

- Changed the specification in which the channel names of each stereo-linked mono channel are not linked. However, the channel names link in the permanent stereo channels such as ST IN, AUX9/10, etc.
- The reverb/ER effects are now available in all FX/InsFX.

Improvements

- Improved the Library screen.
 - Unrecallable Libraries are not listed.
 - You could recall each module such as EQ, COMP, FX, etc from a Preset with different channel types.
- Network setting is now available when no devices are connected to the Network connector.

- The data transfer for Meters is now available between the TF series and the TF Editor even when the DHCP server does not exist with the network setting is set to DHCP.
- When recalling or storing a Scene via the TF Editor, or StageMix, the Scene number and name displays in the TF series are also follow them.

Fixed bugs

- Solved a problem in which when operating the analog gain when the input source setting has been set to "INPUT" and channel link has been set to the channel, the analog gain of the channel using the same input signal of the INPUT port (TF5: CH1-8 and CH33-40, TF3: CH1-16 and CH25-40, TF1: CH1-16 and CH17-32) will link regardless of the input source selection.
- Solved the problem in which the meter could not hold the peak of the OVER level.
- Solved the problem in which some meters would not work properly when loading the setting file with a different meter point setting.
- Solved some minor bugs.

V2.00 (Mac)

This version is not support Mac OS X 10.11.x.

Additional Function

- Added "Ping Pong Delay" and "Dual Pitch" effect types.
- Added the "Manage Library/Scene" window to manage Libraries and Scenes.
- Added the menu to open the website for downloading Channel Libraries (QuickPro Presets).
- Added the "All Nominal" function to set the send level settings of all AUX busses or SUB bus to nominal (0 dB) in the menu of each SEND FROM screen.
- Added the "Dup. STEREO" function to set the send level settings of AUX busses or SUB bus to the same settings of the channel faders in the menu of each SEND FROM screen.
- Added the function to send to the SUB bus from ST IN1/2 or FX RTN 1/2.

NOTE

When recalling a Scene, or a Channel Library stored via the V1.xx version, these send parameters are not changed.

- Added some default Presets in the Channel Library. Some Preset data have been modified. This change will be reflected when executing the “Initialize All Memory” function after updating to V2.00.

Specification Changes

- Changed the specification in which the channel names of each stereo-linked mono channel are not linked. However, the channel names link in the permanent stereo channels such as ST IN, AUX9/10, etc.
- The reverb/ER effects are now available in all FX/InsFX.

Improvements

- Improved the Library screen.
 - Unrecallable Libraries are not listed.
 - You could recall each module such as EQ, COMP, FX, etc from a Preset with different channel types.
- Network setting is now available when no devices are connected to the Network connector.
- The data transfer for Meters is now available between the TF series and the TF Editor even when the DHCP server does not exist with the network setting is set to DHCP.
- When recalling or storing a Scene via the TF Editor, or StageMix, the Scene number and name displays in the TF series are also follow them.

Fixed bugs

- Solved a problem in which when operating the analog gain when the input source setting has been set to “INPUT” and channel link has been set to the channel, the analog gain of the channel using the same input signal of the INPUT port (TF5: CH1-8 and CH33-40, TF3: CH1-16 and CH25-40, TF1: CH1-16 and CH17-32) will link regardless of the input source selection.
- Solved the problem in which the meter could not hold the peak of the OVER level.
- Solved the problem in which some meters would not work properly when loading the setting file with a different meter point setting.
- Solved some minor bugs.

V1.13 (Win)

Improvements

- Improved the lighting/flashing/off function of the ON button in the Channel Strip area for more intuitive understanding of muted channels, specifically when turning on the INPUT button or FX button in the MUTE area, or when operating the ON buttons of DCA1 – 8.
- Improved the function in which an operation in the SENDS ON FADER area is related with an AUX channel to CUE when the CUE function for an AUX channel is set to on.

Fixed bugs

- Solved a problem in which when you zoom up/down the display size via the Zoom function in the Window menu, the previous zoom size could not be restored even if it was set.
- Solved a problem in which when you export a Preset in the LIBRARY window via a touch operation, the application will slow down in action.

Known Issue

- A problem would occur in which some level meters are not displayed at the correct meter point after loading a console data file (.tff) which uses a different meter point.
Changing the meter point in the meter display solves the problem.

V1.13 (Mac)

Specification Changes

- The function of the green button at the upper left of the window has been changed from "full screen" to "maximization."

Improvements

- Improved the lighting/flashing/off function of the ON button in the Channel Strip area for more intuitive understanding of muted channels, specifically when turning on the INPUT button or FX button in the MUTE area, or when operating the ON buttons of DCA1 – 8.
- Improved the function in which an operation in the SENDS ON FADER area is related with an AUX channel to CUE when the CUE function for an AUX channel is set to on.

Fixed bug

- Solved a problem in which when you zoom up/down the display size via the Zoom function in the Window menu, the previous zoom size could not be restored even if it was set.

Known Issues

- The application will slow down in action when you zoom up the display via the Zoom function in a Mac with Retina display.
- A problem would occur in which some level meters are not displayed at the correct meter point after loading a console data file (.tff) which uses a different meter point.
Changing the meter point in the meter display solves the problem.

V1.12 (Win)

Additional Function

- Add a Zoom function (100%, 150%, and 200%) to the Window menu.

Specification Changes

- Changed the About menu to the Help menu. (Windows)
- The default Presets are now set to read-only. In addition, some Presets have been modified.
To apply these changes, execute "Initialize All Memories" after updating the TF Editor to V1.12.

Fixed bugs

- Solved some minor bugs.

Known Issue

- We found a problem that some level meters are not displayed at the correct meter point after loading a console data file (.tff) which uses a different meter point.
Changing the meter point in the meter display solves the problem.

V1.10

The initial release version.